

Advantage Lithium Maintenance

Adv Li Periodic Maintenance

Periodic maintenance is required for the AdvantageLi control panel. The system test as described in section 4.6 lists the procedure for testing the alarm inputs and control panel functions. Depending upon the local authority having jurisdiction (AHJ), maintenance and testing intervals may vary. Refer to sensor manufacturers recommendations regarding the maintenance and testing of field wiring sensors. Inspection intervals are categorized as follows:

Initial Inspection

Verification of system performance must be performed upon completion of initial installation. Use the installation verification checklist included as Appendix 8.1 to record verification of system design and performance. Documentation of installer and contact information are also recorded.

Periodic Inspection

Verification of system performance must be performed upon completion of initial installation. Use the installation verification checklist included as Appendix 8.1 to record verification of system design and performance. Documentation of installer and contact information are also recorded.

Visual Inspection

Verification of system performance must be performed upon completion of initial installation. Use the installation verification checklist included as Appendix 8.1 to record verification of system design and performance. Documentation of installer and contact information are also recorded.

Annual Battery Replacement

At least annually, the primary battery should be replaced. Dispose of the battery as described in section 2 of this manual and in accordance with local regulations.

